## Midi free-standing Beacons / EvoSIGNAL Midi Rotating 115-230VAC YE



ļ

<b>MECHANICA</b> Height	VoSIGNAL L DATA		
Height	L DATA		
-			
		130 mm	
Diameter		85 mm	
Materials		PC	
		PC/ABS	
Dome colour		Yellow	
Housing colour		Grey	
Protection category		IP66	
Connection		Push-in terminal	
cross-sectional area minimum		0,25mm² / 24AWG	
cross-sectional area maximum		1,50mm² / 16AWG	
Type of fixing		Adapter required	
Working temperature minimum		-30°C	
Working temperature maximum		+60°C	
Weight with packaging		222 g	
Product weight		180 g	
ELECTRICAL	DATA		
Operating voltage		115-230V	
Operating voltage type		AC	
Operating voltage frequency		50Hz at 230V 60Hz at 115V	
Operating voltage tolerance		+/- 10%	
Rated operational voltage		230 VAC	
Rated operational current		100 mA	
Rated inrush current		7A	
Protection class		Protection class 2	
Pollution degree		3	
Overvoltage category		II	
Isolation voltage		Ui = 250V; Uimp = 2.500V	
OPTICAL DA	ТА		
Light source		LED	
Light colour		Yellow	
Optical signal image		Revolving	
Service life optical		50,000 h minimum	
Rotation speed (rpm)		180 U/min	
Pulse- & paus	e Duration [ms]	550N, 2780FF	
APPROVAL DATA			
Conforms with	n CE	Yes	


For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

## Midi free-standing Beacons / EvoSIGNAL Midi Rotating 115-230VAC YE

Conforms with RoHS directive	Yes
WEEE	Yes
Conforms with ATEX-directive	No
Conforms with CCC	Yes
Conforms with UL	cULus
UL Type Rating	Type 12
Conforms with FCC	No
Conforms with IC	No
EAC certificate available	Yes
Conforms with UKCA (Importer)	Yes (WERMA (UK) Ltd.)
Conforms with AS-I	No
ICAO Certification	No
Conforms with DNV	No
Conforms with RoHS CN	No
Conforms with VdS	No
MTTF-value [years]	446

Provide the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.

Midi free-standing Beacons / EvoSIGNAL Midi Rotating 115-230VAC YE



Pror additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.